




PARTS MANUAL

BRON RC750 PLOW




RWF INDUSTRIES

873 Devonshire Ave., Woodstock,
Ontario N4S 8Z4
Tel: (519) 421-0036
Toll Free: 1-800-263-1060
Fax: (519) 421-0028
Email: parts@rwfbron.com

PLOW BREAKDOWN

TABLE OF CONTENTS

BACKPLATE	1
FRONT MAST	2
ATTITUDE CYLINDER	3
LOWER LINK.....	4
REAR MAST / BLADE HOLDER.....	5
SWING CYLINDERS	6
BLADE LOCK CYLINDER.....	7
LIFT CYLINDERS	8
WEDGE LOCK CYLINDER	9
DECALS	10




Item	Quantity	Part Number	Description
6	2	114760	SWING CYLINDERS (SEE SECTION 6 FOR ASSEMBLY BREAKDOWN)
13	2	116614	BUSHING RETAINER
15	2	114855	PIN ASSEMBLY
24	2	114860	PIN ASSEMBLY
35	4	15178	BUSHING
37	4	15351	BUSHING
42	4	114858	BOLT SPACER
43	2	114862	BOLT SPACER
50	2	80090	HEX HEAD BOLT
51	4	80110	HEX HEAD BOLT
58	2	80581	WASHER
59	4	80582	WASHER
75	2	90413	SWIVEL RUN TEE
79	4	90469	STRAIGHT BULKHEAD ADAPTER

2 FRONT MAST (30994)

RC750

PARTS MANUAL



rwf_0772

2 FRONT MAST (30994)

RC750


PARTS MANUAL

Item	Quantity	Part Number	Description
5	2	12235	MAIN LIFT CYLINDERS (SEE SECTION 8 FOR ASSEMBLY BREAKDOWN)
6	2	114760	SWING CYLINDERS (SEE SECTION 6 FOR ASSEMBLY BREAKDOWN)
11	2	13414	TRUNNION CAP
13	2	116614	BUSHING RETAINER
15	2	114855	PIN ASSEMBLY
17	2	12271	PIN ASSEMBLY
23	2	114856	PIN ASSEMBLY
24	2	114860	PIN ASSEMBLY
25	2	114863	PIN ASSEMBLY
32	1	12006	SWIVEL BUSHING
35	4	15178	BUSHING
36	2	15181	BUSHING
37	4	15351	BUSHING
39	2	112755	BUSHING
41	4	114851	BOLT SPACER
42	4	114858	BOLT SPACER
43	4	114862	BOLT SPACER
44	5	80680	STRAIGHT GREASE FITTING
45	2	80682	90° GREASE FITTING
46	2	80770	RIVET
50	4	80090	HEX HEAD BOLT
51	12	80110	HEX HEAD BOLT
52	2	80157	HEX HEAD BOLT
53	2	80155	HEX HEAD BOLT
58	4	80581	WASHER
59	12	80582	WASHER
60	2	80584	WASHER
87	2	11983	WARNING SWING AREA DECAL
97	1	30994	MAIN MAST WELDMENT
98	1	9901092	ATTITUDE CYLINDER (SEE SECTION 3 FOR ASSEMBLY BREAKDOWN)

3 ATTITUDE CYLINDER (9901092)

RC750

PARTS MANUAL




rwf_0773

3 ATTITUDE CYLINDER (9901092)

RC750

PARTS MANUAL

Item	Quantity	Part Number	Description
27	1	116155	PIN ASSEMBLY
32	1	12006	SWIVEL BUSHING
34	2	12025	BUSHING
44	2	80680	STRAIGHT GREASE FITTING
98	1	9901092	ATTITUDE CYLINDER
*	1	12492	• SEAL KIT



rwf_0774

4 LOWER LINK (21667)

RC750


PARTS MANUAL

Item	Quantity	Part Number	Description
31	2	12003	SWIVEL BUSHING
33	2	12022	BUSHING
39	2	112755	BUSHING
40	2	115599	BUSHING
41	4	114851	BOLT SPACER
45	4	80682	GREASE FITTING
53	3	80155	HEX HEAD BOLT
57	4	80578	WASHER
60	4	80584	WASHER
79	2	90469	STRAIGHT BULKHEAD ADAPTER
90	1	140501	PIN ASSEMBLY
92	1	21667	LOWER LINK WELDMENT
93	1	141555	HOSE COVER FORM
94	2	85105	TUBE CLAMP
96	2	90468	STRAIGHT BULKHEAD ADAPTER

5 REAR MAST / BLADE HOLDER

RC750

PARTS MANUAL



rwf_0798

5 REAR MAST / BLADE HOLDER

RC750

PARTS MANUAL

Item	Quantity	Part Number	Description
7	1	9900433	BLADE LOCK CYLINDER (SEE SECTION 7 FOR ASSEMBLY BREAKDOWN)
8	1	13417	WEDGE LOCK CYLINDER (SEE SECTION 9 FOR ASSEMBLY BREAKDOWN)
9	1	114615	LOCKING ARM
12	2	13033	RETAINER PLATE
14	1	17639	BLADE HOLDER PIN
16	1	12281	PIN ASSEMBLY
18	1	12264	PIN ASSEMBLY
19	1	12266	PIN ASSEMBLY
20	1	110734	PIN ASSEMBLY
28	1	9900441	HITCH PIN
33	2	12022	BUSHING
34	1	12025	BUSHING
38	5	16311	BUSHING
40	2	115599	BUSHING
41	2	114851	BOLT SPACER
43	4	114862	BOLT SPACER
44	4	80680	STRAIGHT GREASE FITTING
45	4	80682	90° GREASE FITTING
50	4	80090	HEX HEAD BOLT
52	1	80157	HEX HEAD BOLT
53	1	80155	HEX HEAD BOLT
55	1	12294	WASHER PLATE
56	2	80577	WASHER
58	4	80581	WASHER
60	2	80584	WASHER
62	1	80545	SLOTTED NUT
64	1	80660	COTTER PIN
65	1	11171	RESTRICTOR VALVE
66	1	13161	DOUBLE LOCK VALVE
67	1	90021	STRAIGHT ADAPTER
68	3	90073	STRAIGHT ADAPTER
69	2	90070	STRAIGHT ADAPTER
71	2	90245	90° ADAPTER

5 REAR MAST / BLADE HOLDER

RC750


PARTS MANUAL

Item	Quantity	Part Number	Description
75	1	90413	SWIVEL RUN TEE
76	1	90524	RUN TEE
78	1	90359	Straight Swivel Reducer Adapter
79	2	90469	Straight Bulkhead Adapter
90	1	140501	Pin Assembly
96	2	90468	Straight Bulkhead Adapter
98	1	9901092	Attitude Cylinder (SEE SECTION 3 FOR ASSEMBLY BREAKDOWN)

6 SWING CYLINDERS (114760_A)

RC750

PARTS MANUAL




rwf_0799

6 SWING CYLINDERS (114760_A)

RC750

PARTS MANUAL

Item	Quantity	Part Number	Description
6	2	114760	SWING CYLINDERS
*	1 EACH	123814	• SEAL KIT
29	1 EACH	10722	SWIVEL BUSHING
37	2 EACH	15351	BUSHING
44	1 EACH	80680	STRAIGHT GREASE FITTING
45	1 EACH	80682	90° GREASE FITTING
72	2 EACH	90246	90° ADAPTER



rwf_0126

7 BLADE LOCK CYLINDER (9900433_A)

RC750


PARTS MANUAL

Item	Quantity	Part Number	Description
1	1	12001	SWIVEL BUSHING
2	2	16311	BUSHING
3	1	14126	SEAL KIT

8 LIFT CYLINDERS (12235_C)

RC750

PARTS MANUAL



8 LIFT CYLINDERS (12235_C)

RC750


PARTS MANUAL

Item	Quantity	Part Number	Description
5	2	12235	LIFT CYLINDER
*	1 EACH	12217	<ul style="list-style-type: none"> • BARREL WELDMENT
*	1 EACH	12321	<ul style="list-style-type: none"> • ROD WELDMENT
*	1 EACH	12303	<ul style="list-style-type: none"> • PISTON
*	1 EACH	12480	<ul style="list-style-type: none"> • STOVER NUT
*	1 EACH	12253	<ul style="list-style-type: none"> • GLAND
*	1 EACH	12488	<ul style="list-style-type: none"> • SEAL KIT
17	1 EACH	12271	PIN ASSEMBLY
31	1 EACH	12003	SWIVEL BUSHING
41	1 EACH	114851	BOLT SPACER
52	1 EACH	80157	HEX HEAD BOLT
60	1 EACH	80584	WASHER
73	2 EACH	90252	90° ADAPTER
74	1 EACH	90405	SWIVEL BRANCH TEE

9 WEDGE LOCK CYLINDER (13417)

RC750

PARTS MANUAL




rwf_0125

9 WEDGE LOCK CYLINDER (13417)

RC750

PARTS MANUAL

Item	Quantity	Part Number	Description
1	1	80658	COTTER PIN
2	1	80509	STANDARD NUT
3	1	112762	WEDGE
4	1	12494	SEAL KIT
5	1	16909	CYLINDER ASSEMBLY
6	2	16311	BUSHING
7	1	80682	90° GREASE FITTING
8	1	12245	GLAND



10 DECALS

RC750

PARTS MANUAL

Item	Quantity	Part Number	Description
46	2	80770	RIVET
85	1	16923	PATENT # BRON DECAL
86	1	11982	NO WELDING DECAL
87	2	11983	WARNING SWING AREA DECAL
89	1	114950	DRAINAGE PLOW LUBRICATION DECAL